



ITEM 6 IS NOT SHOWN TO ALLOW FOR VISUAL ASSEMBLY PROCEDURE

-REVISIONS-			
LTR.	DESCRIPTION:	DATE:	INT.
A	INITIAL RELEASE	2/10/10	KWR

1. SCREW IN AND TIGHTEN ALL FITTINGS INTO 3 WAY AIR VALVE
3. ZIP TIE THIS MINI ASSEMBLY INTO HANDLE LEFT HALF
4. RUN AIR HOSE 3 THROUGH SMALL HOLE ON HANDLE LEFT HALF
5. RUN AIR HOSE 4 THROUGH SMALL HOLE ON HANDLE RIGHT HALF
6. PLUG AIR HOSE 4 INTO TOP FRONT AIR HOSE FITTING
7. PLUG AIR HOSE 3 INTO TOP BACK AIR HOSE FITTING
8. RUN WATER HOSE THROUGH HALF HOLE ON TOP OF HANDLE LEFT HALF AND THAN THROUGH BOTTOM HALF HOLE, LEAVING 1.5" HANGING OUT BOTTOM (AS SHOWN)
9. SANDWICH HALFS TOGETHER
10. SCREW HALFS TOGETHER USING #4-40 SCREWS
11. PUSH NOZZLE 6 ONTO BOTTOM WATER HOSE
12. PUSH ON PUSH BUTTONS AND TIGHTEN SET SCREWS

11	ZIP_TIE		1
10	URH1-0804-GNT-050_AIR_HOSE_3		1
9	URH1-0804-GNT-050_AIR_HOSE4		1
8	NOZZLE_REV_6		1
7	MAV-3R__3_WAY_AIR_VALVE		1
6	HANDLE_RIGHT_HALF2		1
5	HANDLE_LEFT_HALF2		1
4	5288K15_RUBBER_HOSE		1
3	11916-1-BLK__PUSH_BUTTON		1
2	11792-4-PKG__AIR_HOSE_FITTING		2
1	4-40X3QUARTERS_SCREW		6
ITEM	PART NO.	DESCRIPTION	REQ.

UNLESS OTHERWISE SPECIFIED:			ALL DIMENSIONS ARE IN:	FINISH:	MATERIAL:	Wegmans		
OVER	TO	TOLERANCE				Wegmans	TITLE:HANDLE ASSEMBLY PROCEDURE	
		±	DRAWN BY: KWR	DATE: 2/10/10	SHEET 1 OF 1		DRAWING NUMBER:	SIZE
		±	CHECKED: KWR	DATE: 2/10/10		SCALE:		
		±	ENGINEER:	DATE:			B	
ANGLES		±	RELEASED:	DATE:				