

Motor-Plate Subassembly

- Use pre-drilled motor adapter plate
- Fix motors to plate with M3 screws (2/motor)
- Press-fit pinion Gears

Electronics Subassembly

- Mount PCB with 3 screws on Front plate (B)
- Poke LEDs through hole in Front plate (B)
- Solder wires of LED to PCB
- Solder wires for power output to PCB