



Anet Board V1.0 - Arduino PINs
 arduino hardware files:
github.com/SkyNet3D/anet-board

Testpoints:
 T1/T2 Z-STEP; T3/T4 Z-DIR; T5/T6 E-DIR; T7/T8 E-STEP; T9/T10 Y-STEP;
 T11/T12 Y-DIR; T13/T14 X-DIR; T15/T16 X-STEP; T17/T18 Z-ENABLE;
 T19/T20 XY-ENABLE; T21/T22 SD-SS; T23/T24 SCLK; T25/T26 MOSI; T27/T28 MISO;
 T29/T30 HOTEND; T31/T32 HOTBED; T33/T34 RESET; T35/T36 FAN;
 T37/T38 EXT-SDA; T39/T40 EXT-SCL; T41/T42 EXT-TX1; T43/T44 EXT-RX1;
 T45/T46 EXT-A2; T47/T48 EXT-A1; T49/T50 EXT-A3; T51/T52 EXT-A4;
 T53/T54 BEDTEMP; T55/T56 ENDTEMP; T57/T58 Y-STOP; T59/T60 Z-STOP; T61/T62 X-STOP

ANET3D V1.0 3D-Printer-Board
Anet A6 Anet A8 - 20170616
(Melzi-Clone, changed)