

MSD Team P17453

Meeting Notes

3/9/17

Meeting Accomplishments:

- Did research about valves because the pressure relief valve for the back pressure tank was not working as expected.
 - Was meant for water, not air
 - Was also not the correct type of pressure valve
 - Need a “back pressure” relief valve
- Prepared an order for the correct valve from McMaster-Carr with the necessary attachments
 - Will be placed after back pressure tank and outlet will be plugged to keep the system at 40 PSI
- Attached second pressure transducer onto back pressure tank in order to read both pressures
 - Similar to how pressure is measured on the actual compressor